



Sealed Lead Acid Battery

CHARGE BATTERIES COMPLETELY BEFORE USING SYSTEM FOR FIRST TIME!

- Make sure system power is OFF before charging batteries
- Always fully charge the new batteries in a system before using
- Charge batteries as soon as possible after use, regardless of length of time
- If possible leave system plugged into an outlet during extended periods of storage, if not charge system for a minimum of 24 hrs. once per month

RECHARGE BATTERIES AFTER EVERY USE!

CAUTION: Storing system with partially or fully discharged batteries may cause reduced the battery service life.

**Anchor Audio Customer Service
888-444-6077**

Anchor Audio, Inc.

Portable Sound Systems • Torrance, California



CAUTION To reduce the risk of electric shock, do not remove the cover. No user-serviceable parts inside. Refer servicing to qualified personnel.

WARNING To prevent fire or electric shock, do not expose this equipment to rain or moisture.

CAUTION To reduce the risk of fire, replace only with same type fuse (see specifications).





ATTENTION Pour éviter les risques de choc électrique, ne pas enlever le couvercle. Aucun entretien de pièces intérieures par l'utilisateur. Confier l'entretien au personnel qualifié.

AVIS Pour éviter les risques d'incendie ou d'électrocution, n'exposez pas cet article à la pluie ou à l'humidité.


ATTENTION Pour diminuer le risque d'incendie, remplacer par des fusibles de même type (voir caractéristiques).

EXPLANATION OF GRAPHICAL SYMBOLS

 The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to humans.

 The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

EXPLICATION DES SYMBOLES GRAPHIQUES

 Le symbole éclair avec point de flèche à l'intérieur d'un triangle équilatéral est utilisé pour alerter l'utilisateur de la présence à l'intérieur du coffret de "voltage dangereux" non isolé d'ampleur suffisante pour constituer un risque d'électrocution.

 Le point d'exclamation à l'intérieur d'un triangle équilatéral est employé pour alerter les utilisateurs de la présence d'instructions importantes pour la fonctionnement et l'entretien (service) dans le livret d'instruction accompagnant l'appareil

**Anchor Audio Customer Service
888-444-6077**

Anchor Audio, Inc.

Portable Sound Systems • Torrance, California