



HOW TO: Replace your Liberty Platinum Batteries



5 EASY STEPS!



LET'S GET STARTED



STEP #1

- Flip the Liberty Platinum upside-down and with a Philips head screwdriver, remove the 11 screws that secure the battery base.





STEP #2

- Lay the Liberty Platinum on its back with the speaker grille facing up. Carefully slide out the base to reveal the (2) heavy duty lead acid batteries.





STEP #3

- Turn the base slightly to the right in order to expose the system's battery connections. Unplug all four of the (red and black) wires from the batteries.





STEP #4

- Remove the battery base from the Liberty Platinum system. Take off the metal bracket that supports the batteries by unscrewing the bracket's wing nut.



STEP #5

- Take the dead batteries out from the base and replace them with two fresh batteries.



YOU'RE DONE...CONGRATS!



- Simply reverse the process and test your unit to make sure the system powers on.
- If you have any trouble please give our tech support a call at:

800.262.4671

